

- ♥ Unit 16 & 15/14, Sheridan Close Milperra, Sydney NSW 2213
- **(**02) 9773 0708
- sales@multirange.com.au
- www.multirange.com.au

MAINTENANCE CHART

SANTOEMMA ELITE SILENT

AFTER EVERY USE, ENSURE THAT YOU **COMPLETE THE FOLLOWING 5 STEPS**






Clean out top recovery tank thoroughly, flush with clean water.



Ensure the blue vacuum filter is clean and dry.







Run vacuum for 10 minutes with the top dome removed. This will dry out any moisture that is sitting near the motor.





Always leave clear dome to one side or upside down. This will help the tank not to condensate, consequently extending the life of the vacuum motors.





Vacuum out the brush to remove hair and carpet fluff. This is easiest done when the fluff is dry.





- ♥ Unit 16 & 15/14, Sheridan Close Milperra, Sydney NSW 2213
- **(**02) 9773 0708
- 🔀 sales@multirange.com.au
- www.multirange.com.au

MAINTENANCE CHART

SANS300MVNo1

SANTOEMMA NS300 WAND


AFTER EVERY USE, ENSURE THAT YOU COMPLETE THE FOLLOWING 3 STEPS



1.




Disconnect wand from hose and turn upside down over a drain. This will empty the wand of water to keep it in good condition when not in use. 2.



Remove jet nozzles and holders, clean out regularly. Replace nozzles when they lose their ability to evenly fan the water spray.

3.



Remove carpet fibres from inside fishtail and stainless steel wand. A bottle brush is very useful for this.

